

## M12 firmware update description

**Step 1 :** Double-click M12 Upgrade Tool.exe. The tool interface is as below:


Section 1: Open new firmware file and file path information

Section 2: information about the current firmware version to be downloaded

Section 3: M12 After a correct connection, PID VID information can be displayed

Section 4: The current version of the M12 is displayed after the M12 is connected


Section 5: Download/verification start and progress display area



**Step 2 :** Click "Browse..." Button to open the “. ROM” file to be upgraded

**Step 3 :** Connect you PC and M12 with the USB A to Type-C adapter cable in the package of M12, and connect M12 to the headset. At this time, the corresponding information will be displayed in area 3 and 4, indicating that the connection is successful (please keep M12 connected to the headset during the update process).

**Step 4:** Start updating: Click the "Burn" button in Section 5 to start burning (it takes 1-2 seconds). After the update is successful, the progress bar will be full and the word "succeed" will be displayed. At this time, the version information of Section 4 and Section 2 would be the same.



Unplug the USB cable and reconnect the set. Now the new firmware is working!